

## **User Guide**

# Industrial sewing machine

**Thank you for purchasing our products.**


**For your use safety, please must read the instruction manual before use.**








Up-down needle position	Yes (need device of needle position )	Yes	Yes	Yes
Over current, overload	Yes	Yes	Yes	Yes

<p><b>Port definition</b></p> <p><b>Electric outlet</b></p> <p>② <b>Encoding outlet</b></p> <p>③ <b>Pedal switch Socket</b></p> <p>④ <b>LED light outlet</b></p> <p><b>Outlay needle position outlet</b></p> <p>Please following port definition and outlet color to connection.</p>	<p><b>M-7SE2\</b></p> <p><b>Q1\S1</b></p> <p><b>Built-in</b></p>	
	<p><b>M-6SD2</b></p>	
	<p><b>W1\V1\</b></p> <p><b>P1\N1</b></p>	



### Operation panel description

- 1)  : Working mode,switch the up-down needle position;Parameter mode,setting the parameter.
- 2)  : Working mode,switch the LED light;Parameter mode,save the parameter.
- 3)  : Working mode,adjust the motor speed;Parameter mode,choice and adjust for parameter.

M-6SD2\M-7SE2\Q1\S1	X1\R1	W1\V1\P1\N1

# INTE

## Parameter adjusting and example

1. The panel of four digital Nixie tube display.

Adjust speed by press the “+” , “-” ,key when in standby interface.

1.2 In standby interface ,press the “?” ,when the up needle position indicator light is on ,it is on up needle stop , when the down needle position indicator light is on , it is on down position stop , when the indicator light is off ,the needle position function turn off.

1.3 In standby interface ,press the “S” key , can turn on/off the machine head light.

1.4 Enter in and change the system parameter

When the power is on ,press the “?” key for some seconds ,then press the “+” key , it enters into the parameter mode. The nixietube shows “ P-00” ,

②Press the “+” , “-” key ,can change the parameter.

③After choose the parameter , press the “?” key ,enter into the parameter ,then can change the value of the parameter by “+” , “-” key ,


press the “S” key save the value

1.5 The setting of motor rotate way:

When the power is on ,press the “?” key for some seconds ,then press the “+” key , it enters into the parameter mode. The nixietube shows “ P-00” ,

②Press the “+” key can change parameter to “ P-0 2” ,

③chosen parameter,press “?” ,using “+”



## Error code and parameter

Error code.	Meaning	Code	Meaning
Er01	The error of needle position	01	<p>The motor hall is broken</p> <p>The wheel magnet fall off</p> <p>The connecting of needle signal line is not good</p> <p>Hanging completely disconnected of needle position (NO.⑤output) of the needle position detection</p>
Er02	Can't test the motor signal	02	①pedal signal line connect not good or broken.
Er03	The hall or phase of motor is wrong.	03	<p>①The connecting of 9 needle signal line is not good</p> <p>②The motor hall is broken.</p>
Er04	The protection of locked-rotor	04	<p>The motor is overloading.</p> <p>The connecting of motor power line is not good.</p>
Er05	The hardware is over-current.	05	<p>The motor is overloading.</p> <p>The connecting of motor signal line is not good.</p>
Er07	The serial communication	07	

▲ 本人 工 作 所 在 的 公 司 已 經 開 業 了

— C Y @

<b>P-05</b>	Accelerate the speed	2000~4000	3500	3500 rpm
<b>P-06</b>	Set the needle sewing	0~999	0	
<b>P-07</b>				Retention parameter
<b>P-08</b>				Retention parameter
<b>P-09</b>				Retention parameter
<b>P-10</b>	Automatic Mode switch	0~1	0	No.1 code it's Automatic mode, the function close when turn off power
<b>P-11</b>			0	Retention parameter
<b>P-12</b>			0	Retention parameter
<b>P-13</b>	Selection of motor	0~1	0	1: Old motor 0: normal motor
<b>P-14</b>	Maximum current	50~1000	280	
<b>P-15</b>	Needle position setting	0~1	1	1:means detecting needle position, 0 :means no detect